



MIXING AND DILUTION INSTRUCTIONS

Wallpaper Adhesive

Surface Preparation:

Surfaces should be sound, dry, clean and free from damp, dust and grease.

Absorbent surfaces should be sized prior to hanging wallcovering. We recommend using BEELINE concentrated glue size to size surfaces or mix one sachet contents with 8 pints of cold water.

To mix:

See table for quantity of cold water to use. Remove corner of sachet and sprinkle contents into water stirring briskly for 30 seconds to ensure dispersion. Stir occasionally and use after approximately 3 minutes.

Application:

Always refer to wallcovering manufacturers label for specific hanging instructions. Apply consistent application of adhesive, working right out to the edges.

APPLICATION	QUANTITY OF COLD WATER		APPROX NO. OF ROLLS	QUANTITY OF COLD WATER		APPROX NO. OF ROLLS
	PINTS	LITRES		PINTS	LITRES	
Normal Wallpapers inc. Woodchip	6	3.4	5	12	6.8	10
Vinyl and Washable Papers	5	2.8	4	10	5.6	8
Blown Vinyl	5	2.8	4	10	5.6	8
Embossed Papers	4	2.2	3	8	4.5	6
'Paste the Wall' Wallpapers	4	2.2	3	8	4.5	6
Heavy Embossed Papers	3.5	2.0	2	7	4.0	5
Polystyrene Tiles	3.5	2.0	100 Tiles	7	4.0	200 Tiles