

Recommended Applications	B-I-N	1-2-3	Cover- Stain	AllCoat Solvent
INTERIOR SURFACES				
Drywall	E	E	E	E
Cement Board	E	E	E	E
Plaster (1)	G	E	G	E
New Wood Trims/Doors	E	G	E	G
Plywood	G	G	E	E
Brick & Concrete (1)	G	E	G	G
Aluminium / Galvanised	G	E	G	G
Wood Paneling	E	E	E	E
Fibreglass Doors	G	E	G	G
Glossy Paints & Clear Finishes	E	E	E	E
Ceramic Tile / Formica®	E	E	E	E
Wallcovering (non-porous)	E	E	E	E
EXTERIOR SURFACES				
Cedar & Redwood	*	G	E	*
T1-11 / Plywood	*	E	E	*
Pressure Treated Wood	*	E	E	*
Brick / Concrete / Stucco (1)	*	E	G	*
HardiPlank® / HardiBoard®	*	E	G	*
Glossy Paints	*	E	E	*
Vinyl Siding	*	E	G	*
Aluminium / Galvanised	*	E		*
Wrought Iron	*	NR	GE	*
Steel	*	E	E	*
PVC Pipe	*	E	G	*
STAINS & ODOURS				
Tannin Bleed (2)	E*	G	E	E*
Knots & Sap	E*	NR	NR	NR
Smoke & Fire Damage	E*	NR	E	E*
Water Damage	E*	F	E	E*
Nicotine / Tobacco	F*	NR	E	E*
Mildew Stains (3)	E*	F	E	E*
Pet Stains	E*	NR	E	E*
Asphalt / Tar / Grease	E*	E	NR	NR
Creosote	E*	G	NR	NR
Pencil	E*	E	E	E*
Lipstick / Crayon	E*	E	G	G*
Odour Sealing	E*	NR	NR	NR

E = Excellent (best recommendation)
G = Good (may be used on this surface)
F = Fair (may work, but not as reliable)
NR = Not recommended

NOTES:

- * Interior Use Only (exception: B-I-N may be used for exterior SPOT-priming)
- 1) Allow new masonry, plaster & stucco to cure before coating.
- 2) For best results, allow Bulls Eye 1-2-3 to dry 24 hours before applying topcoat
- 3) Use appropriate cleaner to remove mildew